



Rapid Imaging 201 C HTD

Compact "ALL IN ONE" with "2 HTD DRYER" Drawers

- . All sections are PLC controlled.
- . User friendly touch screen display for easy operation.
- . Visual representation of machine on screen.

PROCESSOR:

- . Automatic plate washout and cleaning.
- . Rotary brushes, with combined rotating and oscillating movements.
- . Permanent self-adhesive plate fixing, no punching.
- . Integrated heater - chiller for solvent temperature control.
- . Automatic solvent replenishment.
- . Solvent fume exhaust system.

DRYER:

- . 2 HTD Dryer drawers.
- . Exhaust system.
- . Timer for each drawer

EXPOSURE:

- . 18 UVA lamps 60W 10/R in drawer type exposure.
- . Automatic defective lamp detection.
- . Cooling fan, automatic lamp temperature regulation.
- . 20 memory channels, working hours counter
- . Easy replacement of lamps on pull-out drawer

LIGHT FINISHER / POST EXPOSURE:

- . 11 UVC lamps 75W
- . 12 UVA lamps 60W
- . Automatic defective lamp detection.
- . 20 memory channels.
- . Exhaust system.

SPECIFICATIONS

Dimensions (WxLxH):

61 x 83 x 49 inches (155 x 211 x 126 cm)

Weight:

1936 lbs. (880 kg)

Power supply:

230 V 3Ph/Pe 50/60 Hz 8.2 Kw 20A
400 V 3Ph/N/Pe 50/60 Hz 8.2 Kw 12A

Maximum plate size:

26 x 32 inches (660 x 810 mm)

Plate thickness:

Up to 0.276 inches (7 mm)

Compressed air supply:

6 bar minimum



For more information, please contact us at:

1257 f Kennestone Circle, Marietta, GA 30066

p 770.420.4006 * 800.464.2931 * f 770.420.2952

www.jvisinc.com

