



## SPECIFICATIONS

### Dimensions (WxLxH):

265 x 172 x 110 cm (104 x 68 x 43 in)  
Height open: 238 cm / 94 in

### Weight:

2200 lbs. (1000 Kg)

### Power supply:

400V 3Ph/N/Pe 50/60Hz 10 Kw 16A  
230V 3Ph/Pe 50/60Hz 10 Kw 26A

### Maximum plate size:

47 x 63 inches / 1200 x 1600 mm

### Plate thickness:

Up to 0.276 inches (7 mm)

### Compressed air supply:

7 bars minimum

### Air exhaust

1500 m3/h minimum for Light Finishing

## Rapid Imaging 400 ECLF

### EXPOSURE:

- . Automatic lid (or manual with active assistance).
- . PLC controlled with touch screen display.
- . Lamp temperature control and regulation.
- . Single side exposure: 38 UVA lamp 80 W 10/R.
- . Cooled vacuum bed (integrated system).
- . Control light for lamp failure indication.
- . 1 yellow inspection lamp.
- . 20 memory channels.
- . Electronic ballasts.

### LIGHT FINISHER - POST EXPOSURE:

- . Light Finishing and Post Exposure drawer.
- . 26 UVC 60W lamps + 27 UVA 80W 10R lamps.
- . Integrated exhaust system.
- . Electronic ballasts for all lamps.
- . Control light for lamp failure indication.

**This unit is available with exposure only,  
without Light Finishing drawer.**

**Model: Concept 400 E or 400 EC**



For more information, please contact us at:

1257 f Kennestone Circle, Marietta, GA 30066

p 770.420.4006 \* 800.464.2931 \* f 770.420.2952

www.jvisinc.com

