



## Rapid Imaging TGT 500 Plate Thickness Gauge Table

Table mounted on rollers.  
Digital micrometer gauge in inches or metric with connectivity to a printer.  
Record highest and lowest point, average variation, average thickness.

### SPECIFICATIONS

**Dimensions (WxLxH):**  
48 x 48 x 43 in (1215 x 1215 x 1100 mm)

**Weight:**  
282 lbs. (128 kg)

**Power supply:**  
230V 50/60 Hz 0.1kW

**Maximum plate size:**  
52 x 80 inches / 1320 x 2032 mm

Features	Advantages
Non binding table top with operation by foot switch.	Easy handling of plate during measurement process.
Extended measuring arm.	For any plate size, up to 52 inch (1 320mm) wide plate.
Measuring arm constructed with a rigid, non deflecting design.	No vibration, precise measurements.
Gravity gauge finger, no pressure.	No pressure on polymer, accurate measurement for low or high durometer plate.
Tolerance presets.	Signal alarm if measurement is out of preset tolerance.

